


**ALIGNMENT PROCEDURE**

PERFORM OPERATIONS IN NUMERICAL ORDER AS SHOWN IN BRACKETS

NOTE - CONNECT SIGNAL GENERATOR TO ONE TURN LOOP PLACED APPROX. ONE FOOT FROM ANTENNA LOOP, FOR OPERATIONS 2, 3, 4, AND 5.

- OPERATION (1) ONLY
- OPERATION (2) RE-ADJUST (2) AT 600 KC/S
- OPERATION (3) ADJUST OSC LOOP AT 540 KC/S
- OPERATION (4) RE-ADJUST (3) AT 1500 KC/S
- OPERATION (5) RE-ADJUST (3) AT 600 KC/S

CONNECT SIGNAL GENERATOR TO THIS POINT THROUGH A .1 MFD. CAPACITOR.



**IF. = 460 KC.**

**AC - DC**

**MODEL**

**501**

**1948-49**

**WESTINGHOUSE**

**DATA SHEET 135**